



Model: K3 STORM

Instruction Manual

Bluetooth Connectivity, AUX-IN, and Built-in Stereo Speakers

Rev 2.1

www.TheK3Company.com

BUTTONS AND CONTROLS



- 1** Volume + Next
- 2** Volume - Previous
- 3** Play / Pause / Speakerphone
- 4** Charging indicator light
- 5** ON /OFF
- 6** Charger port
- 7** AUX in
- 8** NFC area

How to charge your K3 STORM Speaker

1. Plug the USB cable (smaller end) into the DC-IN 5V micro portal/socket of the K3 Speaker.
2. Then, plug the other end (larger end) of USB cable into the USB socket of the devices that have the USB socket. This could be USB portal on your computer, a portable K3 charger with USB charging ports, a wall charger, etc.

Note: The indicator will light red when the speaker is charging. Once the speaker is fully charged, the indicator light will turn off. The required charging time is 2-3 hours dependent on use. Please unplug the USB cable and turn off the speaker if not in use.

TURN ON THE K3 STORM SPEAKER

- Press and hold the  button to turn on the speaker. The indicator light will turn blue and flash rapidly when the speaker is in Bluetooth mode.

TO TURN OFF THE K3 STORM SPEAKER

- Press and hold the  button again until the indicator turns off (i.e. no light).

GETTING CONNECTED

1. Set the Bluetooth function of your external device when the K3 Storm Speaker is on.
2. Set to search Bluetooth device on your external device.

NOTE: The effective distance between your external device and the K3 Storm Speaker is 10 meters or roughly 30 feet.

3. Wait and then find the “K3 STORM” on the paired devices list on your external device and press “K3 STORM”.

NOTE: Dependent on your device software, a window might ask you a password. Fill in “0000” then press “OK” on your external device.


4. A few seconds later the Bluetooth connection will indicate success on external device.

NFC OPERATION








1. Turn the K3 Storm Speaker on. Wait for the Bluetooth indicator light (blue) to flash.
2. Touch the NFC Logo area with the smartphone. Keep touching the speaker with smartphone until the speaker connected. For the first time pairing devices utilizing NFC feature, do not shake smartphone. Please hold smartphone NFC area to speaker NFC logo 2-3 seconds. When the Bluetooth indicator light (blue) stops flashing and remains lit, the speaker is connected to the device. To disconnect the speaker, touch it with the smartphone again.

**Please note, the NFC feature is only applicable if the external device has NFC feature and/or appropriate software.*

HANDS FREE CALLING ~ OPERATION


When an incoming call arrives, the light will flash blue. To answer, short press the  button to answer. Short press the answering button to hang up.

ENJOY MUSIC FROM AN EXTERNAL DEVICE

1. The indicator light will stop flashing when you get your external device paired. (See “Getting connected”)
2. Turn on the music player program on your external device and set it play. Or press  button to set it play.
3. Press and hold the  button to reduce the volume;
4. Press and hold the  button to increase the volume;
5. Just press the  button to skip the start of the previous song;
6. Just press the  button to skip the next song;
7. Press the  button to pause
8. Press the  button again to restart to play.

AUX-IN FUNCTION

The K3 Storm Speaker can play music from some devices that have Aux-in 3.5 mm socket.

1. Plug the Aux-in cable into the 3.5 mm Aux-in socket of the K3 Storm Speaker and plug the other end of Aux-in cable into the Aux-in socket of other devices that have the Aux-in socket;
2. Turn on the unit and it will play music automatically.
3. Press and hold the  button to adjust volume.

SPECIFICATIONS

Output Power 5W X 2 10 Watts Full Range

Frequency Response 20Hz- 20kHz

Bluetooth Profile 2.1. A2DP, AVRCP, HSP, HFP

NFC Near Field Communication

GENERAL

Power Requirements 3.7V Lithium Ion battery capacity: 2000 mAh
Up to ten (10) hours play time. 2-3 hours
charge time.

Dimensions (W x D x H) 2.59" x 2.59" x 6.69" Weight: 15 Ounces

Range 10 meters-33 Feet Open Range

IPX3 Water Resistant IPX3 Certified Rating

Contents K3 Storm Bluetooth Speaker, Micro USB Charge
Cable, 3.5 mm AUX-in cable, User Guide

LEGAL LIABILITY

This battery can be used only with compatible electronic equipment. Please read your equipment packaging instructions to determine whether this battery is compatible with your equipment. The manufacturer shall not be held liable for any damage to electronic equipment during the use of this product.

For any equipment or accessories not suitable for this battery, the manufacturer shall not be held liable for damage caused by misuse or damage incurred by the buyer or the third party rising from any intentional use of the battery. As mentioned above, the manufacturer shall not be held liable for damage caused by misuse of the battery. In case of using this battery on unintended electronic equipment and thus causing damage, you shall be deemed to agree to pay damages to the third party.

WARNING

Read all information and warnings before the use of this product. Improper use of this product may lead to product damage. You ("the Buyer") other than the dealer will be held liable for such damages such as overhead, toxic fume, fire or explosion.

Do not keep the battery in an environment with excessively high temperatures, including intense sunshine. Do not throw battery into fire or other extremely hot environments. Avoid abrupt dropping, fierce bumping, friction or other impact of the battery.

If the battery is damaged such as sinking, puncture, deformation or corrosion due to whatever reason, stop using the battery and send it to local battery recycling center

IMPORTANT SAFETY INSTRUCTIONS	2
BEFORE USE	3
INSTALLATION AND MAINTENANCE	4
<i>BUTTONS AND CONTROLS</i>	4
<i>How to charge your K3 RECESS portable speaker</i>	5
<i>How to charge your device</i>	5
<i>BLUETOOTH CONNECTIVITY</i>	5
<i>TURN ON THE K3 Recess speaker</i>	5
<i>TO TURN OFF THE K3 Recess Speaker</i>	6
<i>GETTING CONNECTED</i>	6
<i>ENJOY MUSIC FROM AN EXTERNAL DEVICE</i>	6
<i>AUX-IN FUNCTION</i>	6
SPECIFICATIONS	7

IMPORTANT SAFETY INSTRUCTIONS



WARNING: To reduce the risk of fire or electric shock, do not submerge this appliance to rain or moisture.

CAUTION: No user serviceable parts inside. Refer servicing to qualified service personnel.



This symbol is intended to alert user to the presence of non-insulated 'dangerous voltage' within the product's enclosure that may be of sufficient magnitude to constitute risk of electric shock to persons.



This symbol is intended to alert user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

1. Read through the manual before operating.
2. Follow all instructions in the manual.
3. Keep the manual for future reference.
4. Keep the apparatus away from heaters, stoves, etc.
5. Do not block any ventilation openings. The ventilation should not be impeded by covering the ventilation openings.
6. Clean the outer silicon shell with a soft cloth slightly moistened with a mild detergent solution. Do not use strong solvents which may cause unpredictable damage to the device and/or finish.
7. Do not use attachments/accessories not recommended by the product manufacturer as they may damage device
8. Power-supply cords should be routed so that they are not likely to be trapped in any way. Also protect the power cord from being walked on or pinched. When removing power cable, please pull directly from the plug, not the cord.
9. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operation instructions.
10. If the device is not used for a period of time, please unplug the power cord.
11. Never try to disassemble batteries. DO not dispose into fire or heater.
12. Refer all servicing to qualified service personnel.
13. Minimum distance 5 cm around the apparatus for sufficient ventilations
14. Please draw attention to the environmental aspects of battery disposal.